Acoustical system, instruction

Due//Matic



The system contains:

Microphone amplifier
Junction box
7 Pcs. microphones
100 m cable 2 x 0,75mm²
33 m cable with 2/5-point plug

Extra accessories: Microphone rack

- A. MIC. RELEASE Switch ON / OFF
- **B. SENSITIVITY**

Tuning control
Standard adjustment:
Between **4** and **5**.

C. Manuel RELEASE
Launch targets by press

Machine bunker



System adjustment: Look on backside of the lid to the amplifier

Microphone no. 0 and 6 are listen phones (noise blocked)

Cable 2 x 0,75 mm²

Microphone cable Plus mounting

Junction box normally installed under desk in house of referee.


Store always the microphone amplifier on a safe and dry place.

230V 1 2 3 4 5 6 0 Junction box



House of referee

Plug mounting



Post in front of shooting stand Mounted with a socket